

#### Ground Fixed

Akadinda Page 1 of 2



Instrument Components:





Eye Straps

5x40mm

Secure Screw

Х4

5x70mm

Screw X4

M10 Wedge M10 x30 SS NutX2 Washer X2





M8x25 SS Washer X8

asher X8 X2



M8 Lock Nut X4








Black Caps



## Installation Instructions








Weight of heaviest part 28kg (Frame)

1. Assemble Akadinda frame comprising 2x 'X'-shaped legs and 1x horizontal beam. (See Assembly Guide). Cover 8 holes on horizontal beam using 4x30mm caps (1.1)

2.Locate M8x80mm eye bolts through pre drilled holes using flat washers on both sides of the timber to prevent the fixing pulling into the timber. Secure in place with M8 nyloc nuts, cover 4 holes in ends using 4x30mm caps. (1.3)

- 3. Place Akadinda in desired location and mark 4 holes for excavation.
- **4. Excavate** holes to min depth **150mm** according to required height for intended players. Hole depth guide below.
- 5. Locate legs in holes and check levels prior to concreting in place. Once happy with location an levels, fill holes using rapid hardening concrete. Leave to dry according to manufactures guidelines.



Height to centre of notes:

KSO 3-5 500mm Depth 400mm
KS1 5-7 650mm Depth 250mm
KS2 7-11 750mm Depth 150mm
Adult 900mm Surface Mounted

Mount eye straps in the centre of the beam 360mm from each end to attach the beaters.



360mm/14" 400mm/16"

500mm/20"

650mm/26"

750mm/30"

900mm/35"

1.5m/59"



### Ground Fixed

Akadinda Page 2 of 2



#### Instrument Components:





M10 x30 SS Washer X2






5x40mm

Secure Screw Χ4

5x70mm

Screw X4





M8 Lock Nut X4













# Assembly Guide PPAKAD







Tools:

TX 25 Driver Bit